

INITIAL MAINTENANCE

- 1. Remove dust and grit by vacuuming (without the beater brush) dry mop or brush your floor.
- 2. Clean the floor using a damp mop using a mild or neutral pH solution to remove any stains. Avoid using multi surface cleaners, bleach, detergents and strong abrasive cleaning agents like organic-solvent, ammonium, or alcohol-based detergents.
- 3. Enjoy your new Adore floor!

DAILY MAINTENANCE

- 1. Vacuum with a hard floor attachment to remove all surface dirt, dust and grit.
- 2. Using a Damp mop to remove surface dirt using a micro-fibre mop and neutral pH cleaner.
- 3. Periodic wet cleaning (damp mop) is necessary to maintain the floors appearance.
- 4. Use an SPC floor cleaner and soft towel to remove any stubborn stains and using a damp mop, go over the area to remove any further residue.

TIPS AND RECOMMANDATIONS

- Use non-staining door mats on the floor. Make sure to clean it regularly.
- Use non-staining floor protectors/felt pads under heavy furniture and equipment.
- Chairs should have clean, smooth, non-staining floor protectors. Ensure there are no nicks or burrs on the protectors. Felt protectors must be cleaned regularly to ensure there is no grit build-up.
- When moving large heavy furniture and equipment, use strips of plywood or Masonite to roll or slide the furniture or equipment.
- Always follow the instructions on your maintenance products. Using too much cleaning product can lead to a greasy residue on top of your floor.

If you feel your situation is not covered by these guidelines, please contact Adore Floors for advice before beginning your maintenance procedures at contact@adorefloors.com.